RapidIO Subsystem Guide

Matt Porter <mporter@kernel.crashing.org>

RapidIO Subsystem Guide

by Matt Porter

Copyright © 2005 MontaVista Software, Inc.

This documentation is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License version 2 as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

For more details see the file COPYING in the source distribution of Linux.

Table of Contents

1. Introduction 1
2. Known Bugs and Limitations 2
    Bugs 2
    Limitations 2
3. RapidIO driver interface 3
    Functions 3
4. Internals 66
    Structures 66
    Enumeration and Discovery 79
    Driver functionality 107
    Device model support 121
    Sysfs support 126
    PPC32 support 128
5. Credits 134

Chapter 1. Introduction

RapidIO is a high speed switched fabric interconnect with features aimed at the embedded market. RapidIO provides support for memory-mapped I/O as well as message-based transactions over the switched fabric network. RapidIO has a standardized discovery mechanism not unlike the PCI bus standard that allows simple detection of devices in a network.

This documentation is provided for developers intending to support RapidIO on new architectures, write new drivers, or to understand the subsystem internals.

Chapter 2. Known Bugs and Limitations

Bugs

None. ;)

Limitations

1. Access/management of RapidIO memory regions is not supported
2. Multiple host enumeration is not supported

Chapter 3. RapidIO driver interface

Drivers are provided a set of calls in order to interface with the subsystem to gather info on devices, request/map memory region resources, and manage mailboxes/doorbells.

Functions

Name

rio_local_read_config_32 — Read 32 bits from local configuration space

Synopsis

```
int rio_local_read_config_32 (struct rio_mport * port, u32 offset, u32
* data);
```

Arguments

port Master port

offset Offset into local configuration space

data Pointer to read data into

Description

Reads 32 bits of data from the specified offset within the local device's configuration space.

Name

rio_local_write_config_32 — Write 32 bits to local configuration space

Synopsis

```
int rio_local_write_config_32 (struct rio_mport * port, u32 offset, u32
data);
```

Arguments

port Master port

offset Offset into local configuration space

data Data to be written

Description

Writes 32 bits of data to the specified offset within the local device's configuration space.

Name

rio_local_read_config_16 — Read 16 bits from local configuration space

Synopsis

```
int rio_local_read_config_16 (struct rio_mport * port, u32 offset, u16
* data);
```

Arguments

port Master port

offset Offset into local configuration space

data Pointer to read data into

Description

Reads 16 bits of data from the specified offset within the local device's configuration space.

Name

rio_local_write_config_16 — Write 16 bits to local configuration space

Synopsis

```
int rio_local_write_config_16 (struct rio_mport * port, u32 offset, u16
data);
```

Arguments

port Master port

offset Offset into local configuration space

data Data to be written

Description

Writes 16 bits of data to the specified offset within the local device's configuration space.

Name

rio_local_read_config_8 — Read 8 bits from local configuration space

Synopsis

```
int rio_local_read_config_8 (struct rio_mport * port, u32 offset, u8
* data);
```

Arguments

port Master port

offset Offset into local configuration space

data Pointer to read data into

Description

Reads 8 bits of data from the specified offset within the local device's configuration space.

Name

rio_local_write_config_8 — Write 8 bits to local configuration space

Synopsis

```
int rio_local_write_config_8 (struct rio_mport * port, u32 offset, u8
data);
```

Arguments

port Master port

offset Offset into local configuration space

data Data to be written

Description

Writes 8 bits of data to the specified offset within the local device's configuration space.

Name

rio_read_config_32 — Read 32 bits from configuration space

Synopsis

```
int rio_read_config_32 (struct rio_dev * rdev, u32 offset, u32 * data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Pointer to read data into

Description

Reads 32 bits of data from the specified offset within the RIO device's configuration space.

Name

rio_write_config_32 — Write 32 bits to configuration space

Synopsis

```
int rio_write_config_32 (struct rio_dev * rdev, u32 offset, u32 data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Data to be written

Description

Writes 32 bits of data to the specified offset within the RIO device's configuration space.

Name

rio_read_config_16 — Read 16 bits from configuration space

Synopsis

```
int rio_read_config_16 (struct rio_dev * rdev, u32 offset, u16 * data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Pointer to read data into

Description

Reads 16 bits of data from the specified offset within the RIO device's configuration space.

Name

rio_write_config_16 — Write 16 bits to configuration space

Synopsis

```
int rio_write_config_16 (struct rio_dev * rdev, u32 offset, u16 data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Data to be written

Description

Writes 16 bits of data to the specified offset within the RIO device's configuration space.

Name

rio_read_config_8 — Read 8 bits from configuration space

Synopsis

```
int rio_read_config_8 (struct rio_dev * rdev, u32 offset, u8 * data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Pointer to read data into

Description

Reads 8 bits of data from the specified offset within the RIO device's configuration space.

Name

rio_write_config_8 — Write 8 bits to configuration space

Synopsis

```
int rio_write_config_8 (struct rio_dev * rdev, u32 offset, u8 data);
```

Arguments

rdev RIO device

offset Offset into device configuration space

data Data to be written

Description

Writes 8 bits of data to the specified offset within the RIO device's configuration space.

Name

rio_send_doorbell — Send a doorbell message to a device

Synopsis

```
int rio_send_doorbell (struct rio_dev * rdev, u16 data);
```

Arguments

rdev RIO device

data Doorbell message data

Description

Send a doorbell message to a RIO device. The doorbell message has a 16-bit info field provided by the *data* argument.

Name

rio_init_mbox_res — Initialize a RIO mailbox resource

Synopsis

```
void rio_init_mbox_res (struct resource * res, int start, int end);
```

Arguments

res resource struct

start start of mailbox range

end end of mailbox range

Description

This function is used to initialize the fields of a resource for use as a mailbox resource. It initializes a range of mailboxes using the start and end arguments.

Name

rio_init_dbell_res — Initialize a RIO doorbell resource

Synopsis

```
void rio_init_dbell_res (struct resource * res, u16 start, u16 end);
```

Arguments

res resource struct

start start of doorbell range

end end of doorbell range

Description

This function is used to initialize the fields of a resource for use as a doorbell resource. It initializes a range of doorbell messages using the start and end arguments.

Name

RIO_DEVICE — macro used to describe a specific RIO device

Synopsis

```
RIO_DEVICE ( dev, ven);
```

Arguments

dev the 16 bit RIO device ID

ven the 16 bit RIO vendor ID

Description

This macro is used to create a struct rio_device_id that matches a specific device. The assembly vendor and assembly device fields will be set to `RIO_ANY_ID`.

Name

rio_add_outb_message — Add RIO message to an outbound mailbox queue

Synopsis

```
int rio_add_outb_message (struct rio_mport * mport, struct rio_dev *
rdev, int mbox, void * buffer, size_t len);
```

Arguments

mport	RIO master port containing the outbound queue
rdev	RIO device the message is be sent to
mbox	The outbound mailbox queue
buffer	Pointer to the message buffer
len	Length of the message buffer

Description

Adds a RIO message buffer to an outbound mailbox queue for transmission. Returns 0 on success.

Name

rio_add_inb_buffer — Add buffer to an inbound mailbox queue

Synopsis

```
int rio_add_inb_buffer (struct rio_mport * mport, int mbox, void *
buffer);
```

Arguments

mport Master port containing the inbound mailbox

mbox The inbound mailbox number

buffer Pointer to the message buffer

Description

Adds a buffer to an inbound mailbox queue for reception. Returns 0 on success.

Name

rio_get_inb_message — Get A RIO message from an inbound mailbox queue

Synopsis

```
void * rio_get_inb_message (struct rio_mport * mport, int mbox);
```

Arguments

mport Master port containing the inbound mailbox

mbox The inbound mailbox number

Description

Get a RIO message from an inbound mailbox queue. Returns 0 on success.

Name

rio_name — Get the unique RIO device identifier

Synopsis

```
const char * rio_name (struct rio_dev * rdev);
```

Arguments

rdev RIO device

Description

Get the unique RIO device identifier. Returns the device identifier string.

Name

rio_get_drvdata — Get RIO driver specific data

Synopsis

```
void * rio_get_drvdata (struct rio_dev * rdev);
```

Arguments

rdev RIO device

Description

Get RIO driver specific data. Returns a pointer to the driver specific data.

Name

rio_set_drvdata — Set RIO driver specific data

Synopsis

```
void rio_set_drvdata (struct rio_dev * rdev, void * data);
```

Arguments

rdev RIO device

data Pointer to driver specific data

Description

Set RIO driver specific data. device struct driver data pointer is set to the *data* argument.

Name

rio_dev_get — Increments the reference count of the RIO device structure

Synopsis

```
struct rio_dev * rio_dev_get (struct rio_dev * rdev);
```

Arguments

rdev RIO device being referenced

Description

Each live reference to a device should be refcounted.

Drivers for RIO devices should normally record such references in their `probe` methods, when they bind to a device, and release them by calling `rio_dev_put`, in their `disconnect` methods.

Name

rio_dev_put — Release a use of the RIO device structure

Synopsis

```
void rio_dev_put (struct rio_dev * rdev);
```

Arguments

rdev RIO device being disconnected

Description

Must be called when a user of a device is finished with it. When the last user of the device calls this function, the memory of the device is freed.

Name

rio_register_driver — register a new RIO driver

Synopsis

```
int rio_register_driver (struct rio_driver * rdrv);
```

Arguments

rdrv the RIO driver structure to register

Description

Adds a struct rio_driver to the list of registered drivers. Returns a negative value on error, otherwise 0. If no error occurred, the driver remains registered even if no device was claimed during registration.

Name

rio_unregister_driver — unregister a RIO driver

Synopsis

```
void rio_unregister_driver (struct rio_driver * rdrv);
```

Arguments

rdrv the RIO driver structure to unregister

Description

Deletes the struct rio_driver from the list of registered RIO drivers, gives it a chance to clean up by calling its `remove` function for each device it was responsible for, and marks those devices as driverless.

Name

rio_local_get_device_id — Get the base/extended device id for a port

Synopsis

```
u16 rio_local_get_device_id (struct rio_mport * port);
```

Arguments

port RIO master port from which to get the deviceid

Description

Reads the base/extended device id from the local device implementing the master port. Returns the 8/16-bit device id.

Name

rio_add_device — Adds a RIO device to the device model

Synopsis

```
int rio_add_device (struct rio_dev * rdev);
```

Arguments

rdev RIO device

Description

Adds the RIO device to the global device list and adds the RIO device to the RIO device list. Creates the generic sysfs nodes for an RIO device.

Name

rio_request_inb_mbox — request inbound mailbox service

Synopsis

```
int rio_request_inb_mbox (struct rio_mport * mport, void * dev_id, int
mbox, int entries, void (*minb) (struct rio_mport * mport, void *dev_id,
int mbox, int slot));
```

Arguments

mport	RIO master port from which to allocate the mailbox resource
dev_id	Device specific pointer to pass on event
mbox	Mailbox number to claim
entries	Number of entries in inbound mailbox queue
minb	Callback to execute when inbound message is received

Description

Requests ownership of an inbound mailbox resource and binds a callback function to the resource. Returns `0` on success.

Name

rio_release_inb_mbox — release inbound mailbox message service

Synopsis

```
int rio_release_inb_mbox (struct rio_mport * mport, int mbox);
```

Arguments

mport RIO master port from which to release the mailbox resource

mbox Mailbox number to release

Description

Releases ownership of an inbound mailbox resource. Returns 0 if the request has been satisfied.

Name

rio_request_outb_mbox — request outbound mailbox service

Synopsis

```
int rio_request_outb_mbox (struct rio_mport * mport, void * dev_id,
int mbox, int entries, void (*moutb) (struct rio_mport * mport, void
*dev_id, int mbox, int slot));
```

Arguments

mport	RIO master port from which to allocate the mailbox resource
dev_id	Device specific pointer to pass on event
mbox	Mailbox number to claim
entries	Number of entries in outbound mailbox queue
moutb	Callback to execute when outbound message is sent

Description

Requests ownership of an outbound mailbox resource and binds a callback function to the resource. Returns 0 on success.

Name

rio_release_outb_mbox — release outbound mailbox message service

Synopsis

```
int rio_release_outb_mbox (struct rio_mport * mport, int mbox);
```

Arguments

mport RIO master port from which to release the mailbox resource

mbox Mailbox number to release

Description

Releases ownership of an inbound mailbox resource. Returns 0 if the request has been satisfied.

Name

rio_request_inb_dbell — request inbound doorbell message service

Synopsis

```
int rio_request_inb_dbell (struct rio_mport * mport, void * dev_id, u16
start, u16 end, void (*dinb) (struct rio_mport * mport, void *dev_id,
u16 src, u16 dst, u16 info));
```

Arguments

mport RIO master port from which to allocate the doorbell resource

dev_id Device specific pointer to pass on event

start Doorbell info range start

end Doorbell info range end

dinb Callback to execute when doorbell is received

Description

Requests ownership of an inbound doorbell resource and binds a callback function to the resource. Returns 0 if the request has been satisfied.

Name

rio_release_inb_dbell — release inbound doorbell message service

Synopsis

```
int rio_release_inb_dbell (struct rio_mport * mport, u16 start, u16 end);
```

Arguments

mport RIO master port from which to release the doorbell resource

start Doorbell info range start

end Doorbell info range end

Description

Releases ownership of an inbound doorbell resource and removes callback from the doorbell event list. Returns 0 if the request has been satisfied.

Name

rio_request_outb_dbell — request outbound doorbell message range

Synopsis

```
struct resource * rio_request_outb_dbell (struct rio_dev * rdev, u16 start, u16 end);
```

Arguments

rdev RIO device from which to allocate the doorbell resource

start Doorbell message range start

end Doorbell message range end

Description

Requests ownership of a doorbell message range. Returns a resource if the request has been satisfied or NULL on failure.

Name

rio_release_outb_dbell — release outbound doorbell message range

Synopsis

```
int rio_release_outb_dbell (struct rio_dev * rdev, struct resource *
res);
```

Arguments

rdev RIO device from which to release the doorbell resource

res Doorbell resource to be freed

Description

Releases ownership of a doorbell message range. Returns 0 if the request has been satisfied.

Name

rio_request_inb_pwrite — request inbound port-write message service

Synopsis

```
int rio_request_inb_pwrite (struct rio_dev * rdev, int (*pwcback)
(struct rio_dev *rdev, union rio_pw_msg *msg, int step));
```

Arguments

rdev RIO device to which register inbound port-write callback routine

pwcback Callback routine to execute when port-write is received

Description

Binds a port-write callback function to the RapidIO device. Returns 0 if the request has been satisfied.

Name

rio_release_inb_pwrite — release inbound port-write message service

Synopsis

```
int rio_release_inb_pwrite (struct rio_dev * rdev);
```

Arguments

rdev RIO device which registered for inbound port-write callback

Description

Removes callback from the rio_dev structure. Returns 0 if the request has been satisfied.

Name

rio_map_inb_region — - Map inbound memory region.

Synopsis

```
int rio_map_inb_region (struct rio_mport * mport, dma_addr_t local, u64
rbase, u32 size, u32 rflags);
```

Arguments

mport Master port.

local physical address of memory region to be mapped

rbase RIO base address assigned to this window

size Size of the memory region

rflags Flags for mapping.

Return

0 -- Success.

This function will create the mapping from RIO space to local memory.

Name

rio_unmap_inb_region — - Unmap the inbound memory region

Synopsis

```
void rio_unmap_inb_region (struct rio_mport * mport, dma_addr_t lstart);
```

Arguments

mport Master port

lstart physical address of memory region to be unmapped

Name

rio_mport_get_physefb — Helper function that returns register offset for Physical Layer Extended Features Block.

Synopsis

```
u32 rio_mport_get_physefb (struct rio_mport * port, int local, u16 destid, u8 hopcount);
```

Arguments

port	Master port to issue transaction
local	Indicate a local master port or remote device access
destid	Destination ID of the device
hopcount	Number of switch hops to the device

Name

rio_get_comptag — Begin or continue searching for a RIO device by component tag

Synopsis

```
struct rio_dev * rio_get_comptag (u32 comp_tag, struct rio_dev * from);
```

Arguments

comp_tag RIO component tag to match

from Previous RIO device found in search, or NULL for new search

Description

Iterates through the list of known RIO devices. If a RIO device is found with a matching *comp_tag*, a pointer to its device structure is returned. Otherwise, NULL is returned. A new search is initiated by passing NULL to the *from* argument. Otherwise, if *from* is not NULL, searches continue from next device on the global list.

Name

rio_set_port_lockout — Sets/clears LOCKOUT bit (RIO EM 1.3) for a switch port.

Synopsis

```
int rio_set_port_lockout (struct rio_dev * rdev, u32 pnum, int lock);
```

Arguments

rdev Pointer to RIO device control structure

pnum Switch port number to set LOCKOUT bit

lock Operation : set (=1) or clear (=0)

Name

rio_enable_rx_tx_port — enable input receiver and output transmitter of given port

Synopsis

```
int rio_enable_rx_tx_port (struct rio_mport * port, int local, u16 destid, u8 hopcount, u8 port_num);
```

Arguments

port	Master port associated with the RIO network
local	local=1 select local port otherwise a far device is reached
destid	Destination ID of the device to check host bit
hopcount	Number of hops to reach the target
port_num	Port (-number on switch) to enable on a far end device

Description

Returns 0 or 1 from on General Control Command and Status Register (EXT_PTR+0x3C)

Name

rio_mport_chk_dev_access — Validate access to the specified device.

Synopsis

```
int rio_mport_chk_dev_access (struct rio_mport * mport, u16 destid, u8
hopcount);
```

Arguments

mport	Master port to send transactions
destid	Device destination ID in network
hopcount	Number of hops into the network

Name

rio_inb_pwrite_handler — process inbound port-write message

Synopsis

```
int rio_inb_pwrite_handler (union rio_pw_msg * pw_msg);
```

Arguments

pw_msg pointer to inbound port-write message

Description

Processes an inbound port-write message. Returns 0 if the request has been satisfied.

Name

rio_mport_get_efb — get pointer to next extended features block

Synopsis

```
u32 rio_mport_get_efb (struct rio_mport * port, int local, u16 destid,
u8 hopcount, u32 from);
```

Arguments

port	Master port to issue transaction
local	Indicate a local master port or remote device access
destid	Destination ID of the device
hopcount	Number of switch hops to the device
from	Offset of current Extended Feature block header (if 0 starts from ExtFeaturePtr)

Name

rio_mport_get_feature — query for devices' extended features

Synopsis

```
u32 rio_mport_get_feature (struct rio_mport * port, int local, u16 destid, u8 hopcount, int ftr);
```

Arguments

port	Master port to issue transaction
local	Indicate a local master port or remote device access
destid	Destination ID of the device
hopcount	Number of switch hops to the device
ftr	Extended feature code

Description

Tell if a device supports a given RapidIO capability. Returns the offset of the requested extended feature block within the device's RIO configuration space or 0 in case the device does not support it. Possible values for *ftr*:

RIO_EFB_PAR_EP_ID LP/LVDS EP Devices

RIO_EFB_PAR_EP_REC_ID LP/LVDS EP Recovery Devices

RIO_EFB_PAR_EP_FREE_ID LP/LVDS EP Free Devices

RIO_EFB_SER_EP_ID LP/Serial EP Devices

RIO_EFB_SER_EP_REC_ID LP/Serial EP Recovery Devices

RIO_EFB_SER_EP_FREE_ID LP/Serial EP Free Devices

Name

rio_get_asm — Begin or continue searching for a RIO device by vid/did/asm_vid/asm_did

Synopsis

```
struct rio_dev * rio_get_asm (u16 vid, u16 did, u16 asm_vid, u16 asm_did,
struct rio_dev * from);
```

Arguments

vid	RIO vid to match or RIO_ANY_ID to match all vids
did	RIO did to match or RIO_ANY_ID to match all dids
asm_vid	RIO asm_vid to match or RIO_ANY_ID to match all asm_vids
asm_did	RIO asm_did to match or RIO_ANY_ID to match all asm_dids
from	Previous RIO device found in search, or NULL for new search

Description

Iterates through the list of known RIO devices. If a RIO device is found with a matching *vid*, *did*, *asm_vid*, *asm_did*, the reference count to the device is incrememted and a pointer to its device structure is returned. Otherwise, NULL is returned. A new search is initiated by passing NULL to the *from* argument. Otherwise, if *from* is not NULL, searches continue from next device on the global list. The reference count for *from* is always decremented if it is not NULL.

Name

rio_get_device — Begin or continue searching for a RIO device by vid/did

Synopsis

```
struct rio_dev * rio_get_device (u16 vid, u16 did, struct rio_dev *
from);
```

Arguments

vid RIO vid to match or RIO_ANY_ID to match all vids

did RIO did to match or RIO_ANY_ID to match all dids

from Previous RIO device found in search, or NULL for new search

Description

Iterates through the list of known RIO devices. If a RIO device is found with a matching *vid* and *did*, the reference count to the device is incrememted and a pointer to its device structure is returned. Otherwise, NULL is returned. A new search is initiated by passing NULL to the *from* argument. Otherwise, if *from* is not NULL, searches continue from next device on the global list. The reference count for *from* is always decremented if it is not NULL.

Name

rio_lock_device — Acquires host device lock for specified device

Synopsis

```
int rio_lock_device (struct rio_mport * port, u16 destid, u8 hopcount,
int wait_ms);
```

Arguments

port	Master port to send transaction
destid	Destination ID for device/switch
hopcount	Hopcount to reach switch
wait_ms	Max wait time in msec (0 = no timeout)

Description

Attepts to acquire host device lock for specified device Returns 0 if device lock acquired or EINVAL if timeout expires.

Name

rio_unlock_device — Releases host device lock for specified device

Synopsis

```
int rio_unlock_device (struct rio_mport * port, u16 destid, u8 hopcount);
```

Arguments

port	Master port to send transaction
destid	Destination ID for device/switch
hopcount	Hopcount to reach switch

Description

Returns 0 if device lock released or EINVAL if fails.

Name

rio_route_add_entry — Add a route entry to a switch routing table

Synopsis

```
int rio_route_add_entry (struct rio_dev * rdev, u16 table, u16 route_destid, u8 route_port, int lock);
```

Arguments

rdev	RIO device
table	Routing table ID
route_destid	Destination ID to be routed
route_port	Port number to be routed
lock	apply a hardware lock on switch device flag (1=lock, 0=no_lock)

Description

If available calls the switch specific `add_entry` method to add a route entry into a switch routing table. Otherwise uses standard RT update method as defined by RapidIO specification. A specific routing table can be selected using the *table* argument if a switch has per port routing tables or the standard (or global) table may be used by passing `RIO_GLOBAL_TABLE` in *table*.

Returns `0` on success or `-EINVAL` on failure.

Name

rio_route_get_entry — Read an entry from a switch routing table

Synopsis

```
int rio_route_get_entry (struct rio_dev * rdev, u16 table, u16 route_destid, u8 * route_port, int lock);
```

Arguments

rdev	RIO device
table	Routing table ID
route_destid	Destination ID to be routed
route_port	Pointer to read port number into
lock	apply a hardware lock on switch device flag (1=lock, 0=no_lock)

Description

If available calls the switch specific `get_entry` method to fetch a route entry from a switch routing table. Otherwise uses standard RT read method as defined by RapidIO specification. A specific routing table can be selected using the *table* argument if a switch has per port routing tables or the standard (or global) table may be used by passing `RIO_GLOBAL_TABLE` in *table*.

Returns `0` on success or `-EINVAL` on failure.

Name

rio_route_clr_table — Clear a switch routing table

Synopsis

```
int rio_route_clr_table (struct rio_dev * rdev, u16 table, int lock);
```

Arguments

rdev RIO device

table Routing table ID

lock apply a hardware lock on switch device flag (1=lock, 0=no_lock)

Description

If available calls the switch specific `clr_table` method to clear a switch routing table. Otherwise uses standard RT write method as defined by RapidIO specification. A specific routing table can be selected using the *table* argument if a switch has per port routing tables or the standard (or global) table may be used by passing `RIO_GLOBAL_TABLE` in *table*.

Returns `0` on success or `-EINVAL` on failure.

Name

rio_request_mport_dma — request RapidIO capable DMA channel associated with specified local RapidIO mport device.

Synopsis

```
struct dma_chan * rio_request_mport_dma (struct rio_mport * mport);
```

Arguments

mport RIO mport to perform DMA data transfers

Description

Returns pointer to allocated DMA channel or NULL if failed.

Name

rio_request_dma — request RapidIO capable DMA channel that supports specified target RapidIO device.

Synopsis

```
struct dma_chan * rio_request_dma (struct rio_dev * rdev);
```

Arguments

rdev RIO device associated with DMA transfer

Description

Returns pointer to allocated DMA channel or NULL if failed.

Name

rio_release_dma — release specified DMA channel

Synopsis

```
void rio_release_dma (struct dma_chan * dchan);
```

Arguments

dchan DMA channel to release

Name

rio_dma_prep_xfer — RapidIO specific wrapper for device_prep_slave_sg callback defined by DMAENGINE.

Synopsis

```
struct dma_async_tx_descriptor * rio_dma_prep_xfer (struct dma_chan * dchan, u16 destid, struct rio_dma_data * data, enum dma_transfer_direction direction, unsigned long flags);
```

Arguments

dchan	DMA channel to configure
destid	target RapidIO device destination ID
data	RIO specific data descriptor
direction	DMA data transfer direction (TO or FROM the device)
flags	dmaengine defined flags

Description

Initializes RapidIO capable DMA channel for the specified data transfer. Uses DMA channel private extension to pass information related to remote target RIO device. Returns pointer to DMA transaction descriptor or NULL if failed.

Name

rio_dma_prep_slave_sg — RapidIO specific wrapper for device_prep_slave_sg callback defined by DMAENGINE.

Synopsis

```
struct dma_async_tx_descriptor * rio_dma_prep_slave_sg (struct rio_dev * rdev, struct dma_chan * dchan, struct rio_dma_data * data, enum dma_transfer_direction direction, unsigned long flags);
```

Arguments

rdev	RIO device control structure
dchan	DMA channel to configure
data	RIO specific data descriptor
direction	DMA data transfer direction (TO or FROM the device)
flags	dmaengine defined flags

Description

Initializes RapidIO capable DMA channel for the specified data transfer. Uses DMA channel private extension to pass information related to remote target RIO device. Returns pointer to DMA transaction descriptor or NULL if failed.

Name

rio_register_scan — enumeration/discovery method registration interface

Synopsis

```
int rio_register_scan (int mport_id, struct rio_scan * scan_ops);
```

Arguments

mport_id mport device ID for which fabric scan routine has to be set (RIO_MPORT_ANY = set for all available mports)

scan_ops enumeration/discovery operations structure

Description

Registers enumeration/discovery operations with RapidIO subsystem and attaches it to the specified mport device (or all available mports if RIO_MPORT_ANY is specified).

Returns error if the mport already has an enumerator attached to it. In case of RIO_MPORT_ANY skips mports with valid scan routines (no error).

Name

rio_unregister_scan — removes enumeration/discovery method from mport

Synopsis

```
int rio_unregister_scan (int mport_id, struct rio_scan * scan_ops);
```

Arguments

mport_id mport device ID for which fabric scan routine has to be unregistered (RIO_MPORT_ANY = apply to all mports that use the specified scan_ops)

scan_ops enumeration/discovery operations structure

Description

Removes enumeration or discovery method assigned to the specified mport device. If RIO_MPORT_ANY is specified, removes the specified operations from all mports that have them attached.

Chapter 4. Internals

This chapter contains the autogenerated documentation of the RapidIO subsystem.

Structures

Name

struct rio_switch — RIO switch info

Synopsis

```
struct rio_switch {
  struct list_head node;
  u8 * route_table;
  u32 port_ok;
  struct rio_switch_ops * ops;
  spinlock_t lock;
  struct rio_dev * nextdev[0];
};
```

Members

node	Node in global list of switches
route_table	Copy of switch routing table
port_ok	Status of each port (one bit per port) - OK=1 or UNINIT=0
ops	pointer to switch-specific operations
lock	lock to serialize operations updates
nextdev[0]	Array of per-port pointers to the next attached device

Name

struct rio_switch_ops — Per-switch operations

Synopsis

```
struct rio_switch_ops {
  struct module * owner;
  int (* add_entry) (struct rio_mport *mport, u16 destid, u8 hopcount,u16 table, u
  int (* get_entry) (struct rio_mport *mport, u16 destid, u8 hopcount,u16 table, u
  int (* clr_table) (struct rio_mport *mport, u16 destid, u8 hopcount,u16 table);
  int (* set_domain) (struct rio_mport *mport, u16 destid, u8 hopcount,u8 sw_domai
  int (* get_domain) (struct rio_mport *mport, u16 destid, u8 hopcount,u8 *sw_doma
  int (* em_init) (struct rio_dev *dev);
  int (* em_handle) (struct rio_dev *dev, u8 swport);
};
```

Members

owner	The module owner of this structure
add_entry	Callback for switch-specific route add function
get_entry	Callback for switch-specific route get function
clr_table	Callback for switch-specific clear route table function
set_domain	Callback for switch-specific domain setting function
get_domain	Callback for switch-specific domain get function
em_init	Callback for switch-specific error management init function
em_handle	Callback for switch-specific error management handler function

Description

Defines the operations that are necessary to initialize/control a particular RIO switch device.

Name

struct rio_dev — RIO device info

Synopsis

```
struct rio_dev {
  struct list_head global_list;
  struct list_head net_list;
  struct rio_net * net;
  bool do_enum;
  u16 did;
  u16 vid;
  u32 device_rev;
  u16 asm_did;
  u16 asm_vid;
  u16 asm_rev;
  u16 efptr;
  u32 pef;
  u32 swpinfo;
  u32 src_ops;
  u32 dst_ops;
  u32 comp_tag;
  u32 phys_efptr;
  u32 em_efptr;
  u64 dma_mask;
  struct rio_driver * driver;
  struct device dev;
  struct resource riores[RIO_MAX_DEV_RESOURCES];
  int (* pwcback) (struct rio_dev *rdev, union rio_pw_msg *msg, int step);
  u16 destid;
  u8 hopcount;
  struct rio_dev * prev;
  struct rio_switch rswitch[0];
};
```

Members

global_list	Node in list of all RIO devices
net_list	Node in list of RIO devices in a network
net	Network this device is a part of
do_enum	Enumeration flag
did	Device ID
vid	Vendor ID
device_rev	Device revision
asm_did	Assembly device ID
asm_vid	Assembly vendor ID

asm_rev	Assembly revision
efptr	Extended feature pointer
pef	Processing element features
swpinfo	Switch port info
src_ops	Source operation capabilities
dst_ops	Destination operation capabilities
comp_tag	RIO component tag
phys_efptr	RIO device extended features pointer
em_efptr	RIO Error Management features pointer
dma_mask	Mask of bits of RIO address this device implements
driver	Driver claiming this device
dev	Device model device
riores[RIO_MAX_DEV_RESOURCES]	RIO resources this device owns
pwcback	port-write callback function for this device
destid	Network destination ID (or associated destid for switch)
hopcount	Hopcount to this device
prev	Previous RIO device connected to the current one
rswitch[0]	struct rio_switch (if valid for this device)

Name

struct rio_msg — RIO message event

Synopsis

```
struct rio_msg {
  struct resource * res;
  void (* mcback) (struct rio_mport * mport, void *dev_id, int mbox, int slot);
};
```

Members

res Mailbox resource

mcback Message event callback

Name

struct rio_dbell — RIO doorbell event

Synopsis

```
struct rio_dbell {
  struct list_head node;
  struct resource * res;
  void (* dinb) (struct rio_mport *mport, void *dev_id, u16 src, u16 dst, u16 info
  void * dev_id;
};
```

Members

node — Node in list of doorbell events

res — Doorbell resource

dinb — Doorbell event callback

dev_id — Device specific pointer to pass on event

Name

struct rio_mport — RIO master port info

Synopsis

```
struct rio_mport {
  struct list_head dbells;
  struct list_head node;
  struct list_head nnode;
  struct resource iores;
  struct resource riores[RIO_MAX_MPORT_RESOURCES];
  struct rio_msg inb_msg[RIO_MAX_MBOX];
  struct rio_msg outb_msg[RIO_MAX_MBOX];
  int host_deviceid;
  struct rio_ops * ops;
  unsigned char id;
  unsigned char index;
  unsigned int sys_size;
  enum rio_phy_type phy_type;
  u32 phys_efptr;
  unsigned char name[RIO_MAX_MPORT_NAME];
  struct device dev;
  void * priv;
#ifdef CONFIG_RAPIDIO_DMA_ENGINE
  struct dma_device dma;
#endif
  struct rio_scan * nscan;
};
```

Members

dbells	List of doorbell events
node	Node in global list of master ports
nnode	Node in network list of master ports
iores	I/O mem resource that this master port interface owns
riores[RIO_MAX_MPORT_RESOURCES]	RIO resources that this master port interfaces owns
inb_msg[RIO_MAX_MBOX]	RIO inbound message event descriptors
outb_msg[RIO_MAX_MBOX]	RIO outbound message event descriptors
host_deviceid	Host device ID associated with this master port
ops	configuration space functions
id	Port ID, unique among all ports
index	Port index, unique among all port interfaces of the same type
sys_size	RapidIO common transport system size

phy_type	RapidIO phy type
phys_efptr	RIO port extended features pointer
name[RIO_MAX_MPORT_NAME]	Port name string
dev	device structure associated with an mport
priv	Master port private data
dma	DMA device associated with mport
nscan	RapidIO network enumeration/discovery operations

Name

struct rio_net — RIO network info

Synopsis

```
struct rio_net {
  struct list_head node;
  struct list_head devices;
  struct list_head switches;
  struct list_head mports;
  struct rio_mport * hport;
  unsigned char id;
  struct rio_id_table destid_table;
};
```

Members

node	Node in global list of RIO networks
devices	List of devices in this network
switches	List of switches in this network
mports	List of master ports accessing this network
hport	Default port for accessing this network
id	RIO network ID
destid_table	destID allocation table

Name

struct rio_ops — Low-level RIO configuration space operations

Synopsis

```
struct rio_ops {
  int (* lcread) (struct rio_mport *mport, int index, u32 offset, int len,u32 *dat
  int (* lcwrite) (struct rio_mport *mport, int index, u32 offset, int len,u32 dat
  int (* cread) (struct rio_mport *mport, int index, u16 destid,u8 hopcount, u32 o
  int (* cwrite) (struct rio_mport *mport, int index, u16 destid,u8 hopcount, u32
  int (* dsend) (struct rio_mport *mport, int index, u16 destid, u16 data);
  int (* pwenable) (struct rio_mport *mport, int enable);
  int (* open_outb_mbox) (struct rio_mport *mport, void *dev_id,int mbox, int entr
  void (* close_outb_mbox) (struct rio_mport *mport, int mbox);
  int (* open_inb_mbox) (struct rio_mport *mport, void *dev_id,int mbox, int entri
  void (* close_inb_mbox) (struct rio_mport *mport, int mbox);
  int (* add_outb_message) (struct rio_mport *mport, struct rio_dev *rdev,int mbox
  int (* add_inb_buffer) (struct rio_mport *mport, int mbox, void *buf);
  void *(* get_inb_message) (struct rio_mport *mport, int mbox);
  int (* map_inb) (struct rio_mport *mport, dma_addr_t lstart,u64 rstart, u32 size
  void (* unmap_inb) (struct rio_mport *mport, dma_addr_t lstart);
};
```

Members

lcread	Callback to perform local (master port) read of config space.
lcwrite	Callback to perform local (master port) write of config space.
cread	Callback to perform network read of config space.
cwrite	Callback to perform network write of config space.
dsend	Callback to send a doorbell message.
pwenable	Callback to enable/disable port-write message handling.
open_outb_mbox	Callback to initialize outbound mailbox.
close_outb_mbox	Callback to shut down outbound mailbox.
open_inb_mbox	Callback to initialize inbound mailbox.
close_inb_mbox	Callback to shut down inbound mailbox.
add_outb_message	Callback to add a message to an outbound mailbox queue.
add_inb_buffer	Callback to add a buffer to an inbound mailbox queue.
get_inb_message	Callback to get a message from an inbound mailbox queue.
map_inb	Callback to map RapidIO address region into local memory space.
unmap_inb	Callback to unmap RapidIO address region mapped with `map_inb`.

Name

struct rio_driver — RIO driver info

Synopsis

```
struct rio_driver {
  struct list_head node;
  char * name;
  const struct rio_device_id * id_table;
  int (* probe) (struct rio_dev * dev, const struct rio_device_id * id);
  void (* remove) (struct rio_dev * dev);
  int (* suspend) (struct rio_dev * dev, u32 state);
  int (* resume) (struct rio_dev * dev);
  int (* enable_wake) (struct rio_dev * dev, u32 state, int enable);
  struct device_driver driver;
};
```

Members

node	Node in list of drivers
name	RIO driver name
id_table	RIO device ids to be associated with this driver
probe	RIO device inserted
remove	RIO device removed
suspend	RIO device suspended
resume	RIO device awakened
enable_wake	RIO device enable wake event
driver	LDM driver struct

Description

Provides info on a RIO device driver for insertion/removal and power management purposes.

Name

struct rio_scan — RIO enumeration and discovery operations

Synopsis

```
struct rio_scan {
  struct module * owner;
  int (* enumerate) (struct rio_mport *mport, u32 flags);
  int (* discover) (struct rio_mport *mport, u32 flags);
};
```

Members

owner	The module owner of this structure
enumerate	Callback to perform RapidIO fabric enumeration.
discover	Callback to perform RapidIO fabric discovery.

Name

struct rio_scan_node — list node to register RapidIO enumeration and discovery methods with RapidIO core.

Synopsis

```
struct rio_scan_node {
  int mport_id;
  struct list_head node;
  struct rio_scan * ops;
};
```

Members

mport_id	ID of an mport (net) serviced by this enumerator
node	node in global list of registered enumerators
ops	RIO enumeration and discovery operations

Enumeration and Discovery

Name

rio_destid_alloc — Allocate next available destID for given network

Synopsis

```
u16 rio_destid_alloc (struct rio_net * net);
```

Arguments

net RIO network

Description

Returns next available device destination ID for the specified RIO network. Marks allocated ID as one in use. Returns RIO_INVALID_DESTID if new destID is not available.

Name

rio_destid_reserve — Reserve the specivied destID

Synopsis

```
int rio_destid_reserve (struct rio_net * net, u16 destid);
```

Arguments

net RIO network

destid destID to reserve

Description

Tries to reserve the specified destID. Returns 0 if successful.

Name

rio_destid_free — free a previously allocated destID

Synopsis

```
void rio_destid_free (struct rio_net * net, u16 destid);
```

Arguments

net RIO network

destid destID to free

Description

Makes the specified destID available for use.

Name

rio_destid_first — return first destID in use

Synopsis

```
u16 rio_destid_first (struct rio_net * net);
```

Arguments

net RIO network

Name

rio_destid_next — return next destID in use

Synopsis

```
u16 rio_destid_next (struct rio_net * net, u16 from);
```

Arguments

net RIO network

from destination ID from which search shall continue

Name

rio_get_device_id — Get the base/extended device id for a device

Synopsis

```
u16 rio_get_device_id (struct rio_mport * port, u16 destid, u8 hopcount);
```

Arguments

port	RIO master port
destid	Destination ID of device
hopcount	Hopcount to device

Description

Reads the base/extended device id from a device. Returns the 8/16-bit device ID.

Name

rio_set_device_id — Set the base/extended device id for a device

Synopsis

```
void rio_set_device_id (struct rio_mport * port, u16 destid, u8 hopcount,
u16 did);
```

Arguments

port	RIO master port
destid	Destination ID of device
hopcount	Hopcount to device
did	Device ID value to be written

Description

Writes the base/extended device id from a device.

Name

rio_local_set_device_id — Set the base/extended device id for a port

Synopsis

```
void rio_local_set_device_id (struct rio_mport * port, u16 did);
```

Arguments

port RIO master port

did Device ID value to be written

Description

Writes the base/extended device id from a device.

Name

rio_clear_locks — Release all host locks and signal enumeration complete

Synopsis

```
int rio_clear_locks (struct rio_net * net);
```

Arguments

net RIO network to run on

Description

Marks the component tag CSR on each device with the enumeration complete flag. When complete, it then release the host locks on each device. Returns 0 on success or `-EINVAL` on failure.

Name

rio_enum_host — Set host lock and initialize host destination ID

Synopsis

```
int rio_enum_host (struct rio_mport * port);
```

Arguments

port Master port to issue transaction

Description

Sets the local host master port lock and destination ID register with the host device ID value. The host device ID value is provided by the platform. Returns `0` on success or `-1` on failure.

Name

rio_device_has_destid — Test if a device contains a destination ID register

Synopsis

```
int rio_device_has_destid (struct rio_mport * port, int src_ops, int
dst_ops);
```

Arguments

port Master port to issue transaction

src_ops RIO device source operations

dst_ops RIO device destination operations

Description

Checks the provided *src_ops* and *dst_ops* for the necessary transaction capabilities that indicate whether or not a device will implement a destination ID register. Returns 1 if true or 0 if false.

Name

rio_release_dev — Frees a RIO device struct

Synopsis

```
void rio_release_dev (struct device * dev);
```

Arguments

dev LDM device associated with a RIO device struct

Description

Gets the RIO device struct associated a RIO device struct. The RIO device struct is freed.

Name

rio_is_switch — Tests if a RIO device has switch capabilities

Synopsis

```
int rio_is_switch (struct rio_dev * rdev);
```

Arguments

rdev RIO device

Description

Gets the RIO device Processing Element Features register contents and tests for switch capabilities. Returns 1 if the device is a switch or 0 if it is not a switch. The RIO device struct is freed.

Name

rio_setup_device — Allocates and sets up a RIO device

Synopsis

```
struct rio_dev * rio_setup_device (struct rio_net * net, struct rio_mport
* port, u16 destid, u8 hopcount, int do_enum);
```

Arguments

net	RIO network
port	Master port to send transactions
destid	Current destination ID
hopcount	Current hopcount
do_enum	Enumeration/Discovery mode flag

Description

Allocates a RIO device and configures fields based on configuration space contents. If device has a destination ID register, a destination ID is either assigned in enumeration mode or read from configuration space in discovery mode. If the device has switch capabilities, then a switch is allocated and configured appropriately. Returns a pointer to a RIO device on success or NULL on failure.

Name

rio_sport_is_active — Tests if a switch port has an active connection.

Synopsis

```
int rio_sport_is_active (struct rio_mport * port, u16 destid, u8 hopcount, int sport);
```

Arguments

port	Master port to send transaction
destid	Associated destination ID for switch
hopcount	Hopcount to reach switch
sport	Switch port number

Description

Reads the port error status CSR for a particular switch port to determine if the port has an active link. Returns `RIO_PORT_N_ERR_STS_PORT_OK` if the port is active or `0` if it is inactive.

Name

rio_get_host_deviceid_lock — Reads the Host Device ID Lock CSR on a device

Synopsis

```
u16 rio_get_host_deviceid_lock (struct rio_mport * port, u8 hopcount);
```

Arguments

port Master port to send transaction

hopcount Number of hops to the device

Description

Used during enumeration to read the Host Device ID Lock CSR on a RIO device. Returns the value of the lock register.

Name

rio_enum_peer — Recursively enumerate a RIO network through a master port

Synopsis

```
int rio_enum_peer (struct rio_net * net, struct rio_mport * port, u8
hopcount, struct rio_dev * prev, int prev_port);
```

Arguments

net	RIO network being enumerated
port	Master port to send transactions
hopcount	Number of hops into the network
prev	Previous RIO device connected to the enumerated one
prev_port	Port on previous RIO device

Description

Recursively enumerates a RIO network. Transactions are sent via the master port passed in *port*.

Name

rio_enum_complete — Tests if enumeration of a network is complete

Synopsis

```
int rio_enum_complete (struct rio_mport * port);
```

Arguments

port Master port to send transaction

Description

Tests the PGCCSR discovered bit for non-zero value (enumeration complete flag). Return `1` if enumeration is complete or `0` if enumeration is incomplete.

Name

rio_disc_peer — Recursively discovers a RIO network through a master port

Synopsis

```
int rio_disc_peer (struct rio_net * net, struct rio_mport * port, u16
destid, u8 hopcount, struct rio_dev * prev, int prev_port);
```

Arguments

net	RIO network being discovered
port	Master port to send transactions
destid	Current destination ID in network
hopcount	Number of hops into the network
prev	previous rio_dev
prev_port	previous port number

Description

Recursively discovers a RIO network. Transactions are sent via the master port passed in *port*.

Name

rio_mport_is_active — Tests if master port link is active

Synopsis

```
int rio_mport_is_active (struct rio_mport * port);
```

Arguments

port Master port to test

Description

Reads the port error status CSR for the master port to determine if the port has an active link. Returns `RIO_PORT_N_ERR_STS_PORT_OK` if the master port is active or `0` if it is inactive.

Name

rio_alloc_net — Allocate and configure a new RIO network

Synopsis

```
struct rio_net * rio_alloc_net (struct rio_mport * port, int do_enum,
u16 start);
```

Arguments

port Master port associated with the RIO network

do_enum Enumeration/Discovery mode flag

start logical minimal start id for new net

Description

Allocates a RIO network structure, initializes per-network list heads, and adds the associated master port to the network list of associated master ports. Returns a RIO network pointer on success or NULL on failure.

Name

rio_update_route_tables — Updates route tables in switches

Synopsis

```
void rio_update_route_tables (struct rio_net * net);
```

Arguments

net RIO network to run update on

Description

For each enumerated device, ensure that each switch in a system has correct routing entries. Add routes for devices that where unknown dirung the first enumeration pass through the switch.

Name

rio_init_em — Initializes RIO Error Management (for switches)

Synopsis

```
void rio_init_em (struct rio_dev * rdev);
```

Arguments

rdev RIO device

Description

For each enumerated switch, call device-specific error management initialization routine (if supplied by the switch driver).

Name

rio_pw_enable — Enables/disables port-write handling by a master port

Synopsis

```
void rio_pw_enable (struct rio_mport * port, int enable);
```

Arguments

port Master port associated with port-write handling

enable 1=enable, 0=disable

Name

rio_enum_mport — Start enumeration through a master port

Synopsis

```
int rio_enum_mport (struct rio_mport * mport, u32 flags);
```

Arguments

mport Master port to send transactions

flags Enumeration control flags

Description

Starts the enumeration process. If somebody has enumerated our master port device, then give up. If not and we have an active link, then start recursive peer enumeration. Returns `0` if enumeration succeeds or `-EBUSY` if enumeration fails.

Name

rio_build_route_tables — Generate route tables from switch route entries

Synopsis

```
void rio_build_route_tables (struct rio_net * net);
```

Arguments

net RIO network to run route tables scan on

Description

For each switch device, generate a route table by copying existing route entries from the switch.

Name

rio_disc_mport — Start discovery through a master port

Synopsis

```
int rio_disc_mport (struct rio_mport * mport, u32 flags);
```

Arguments

`mport` Master port to send transactions

`flags` discovery control flags

Description

Starts the discovery process. If we have an active link, then wait for the signal that enumeration is complete (if wait is allowed). When enumeration completion is signaled, start recursive peer discovery. Returns `0` if discovery succeeds or `-EBUSY` on failure.

Name

rio_basic_attach —

Synopsis

```
int rio_basic_attach ( void);
```

Arguments

void no arguments

Description

When this enumeration/discovery method is loaded as a module this function registers its specific enumeration and discover routines for all available RapidIO mport devices. The “scan” command line parameter controls ability of the module to start RapidIO enumeration/discovery automatically.

Returns 0 for success or -EIO if unable to register itself.

This enumeration/discovery method cannot be unloaded and therefore does not provide a matching cleanup_module routine.

Driver functionality

Name

rio_setup_inb_dbell — bind inbound doorbell callback

Synopsis

```
int rio_setup_inb_dbell (struct rio_mport * mport, void * dev_id, struct
resource * res, void (*dinb) (struct rio_mport * mport, void *dev_id,
u16 src, u16 dst, u16 info));
```

Arguments

mport RIO master port to bind the doorbell callback

dev_id Device specific pointer to pass on event

res Doorbell message resource

dinb Callback to execute when doorbell is received

Description

Adds a doorbell resource/callback pair into a port's doorbell event list. Returns 0 if the request has been satisfied.

Name

rio_chk_dev_route — Validate route to the specified device.

Synopsis

```
int rio_chk_dev_route (struct rio_dev * rdev, struct rio_dev ** nrdev,
int * npnum);
```

Arguments

rdev RIO device failed to respond

nrdev Last active device on the route to rdev

npnum nrdev's port number on the route to rdev

Description

Follows a route to the specified RIO device to determine the last available device (and corresponding RIO port) on the route.

Name

rio_chk_dev_access — Validate access to the specified device.

Synopsis

```
int rio_chk_dev_access (struct rio_dev * rdev);
```

Arguments

rdev Pointer to RIO device control structure

Name

rio_get_input_status — Sends a Link-Request/Input-Status control symbol and returns link-response (if requested).

Synopsis

```
int rio_get_input_status (struct rio_dev * rdev, int pnum, u32 * lnkresp);
```

Arguments

rdev RIO devive to issue Input-status command

pnum Device port number to issue the command

lnkresp Response from a link partner

Name

rio_clr_err_stopped — Clears port Error-stopped states.

Synopsis

```
int rio_clr_err_stopped (struct rio_dev * rdev, u32 pnum, u32 err_status);
```

Arguments

rdev	Pointer to RIO device control structure
pnum	Switch port number to clear errors
err_status	port error status (if 0 reads register from device)

Name

rio_std_route_add_entry — Add switch route table entry using standard registers defined in RIO specification rev.1.3

Synopsis

```
int rio_std_route_add_entry (struct rio_mport * mport, u16 destid, u8 hopcount, u16 table, u16 route_destid, u8 route_port);
```

Arguments

mport	Master port to issue transaction
destid	Destination ID of the device
hopcount	Number of switch hops to the device
table	routing table ID (global or port-specific)
route_destid	destID entry in the RT
route_port	destination port for specified destID

Name

rio_std_route_get_entry — Read switch route table entry (port number) associated with specified destID using standard registers defined in RIO specification rev.1.3

Synopsis

```
int rio_std_route_get_entry (struct rio_mport * mport, u16 destid, u8 hopcount, u16 table, u16 route_destid, u8 * route_port);
```

Arguments

mport	Master port to issue transaction
destid	Destination ID of the device
hopcount	Number of switch hops to the device
table	routing table ID (global or port-specific)
route_destid	destID entry in the RT
route_port	returned destination port for specified destID

Name

rio_std_route_clr_table — Clear swotch route table using standard registers defined in RIO specification rev.1.3.

Synopsis

```
int rio_std_route_clr_table (struct rio_mport * mport, u16 destid, u8 hopcount, u16 table);
```

Arguments

mport	Master port to issue transaction
destid	Destination ID of the device
hopcount	Number of switch hops to the device
table	routing table ID (global or port-specific)

Name

rio_find_mport — find RIO mport by its ID

Synopsis

```
struct rio_mport * rio_find_mport (int mport_id);
```

Arguments

`mport_id` number (ID) of mport device

Description

Given a RIO mport number, the desired mport is located in the global list of mports. If the mport is found, a pointer to its data structure is returned. If no mport is found, `NULL` is returned.

Name

rio_mport_scan — execute enumeration/discovery on the specified mport

Synopsis

```
int rio_mport_scan (int mport_id);
```

Arguments

mport_id number (ID) of mport device

Name

RIO_LOP_READ — Generate rio_local_read_config_* functions

Synopsis

```
RIO_LOP_READ ( size, type, len);
```

Arguments

size Size of configuration space read (8, 16, 32 bits)

type C type of value argument

len Length of configuration space read (1, 2, 4 bytes)

Description

Generates rio_local_read_config_* functions used to access configuration space registers on the local device.

Name

RIO_LOP_WRITE — Generate rio_local_write_config_* functions

Synopsis

```
RIO_LOP_WRITE ( size, type, len);
```

Arguments

size Size of configuration space write (8, 16, 32 bits)

type C type of value argument

len Length of configuration space write (1, 2, 4 bytes)

Description

Generates rio_local_write_config_* functions used to access configuration space registers on the local device.

Name

RIO_OP_READ — Generate rio_mport_read_config_* functions

Synopsis

```
RIO_OP_READ ( size, type, len);
```

Arguments

size Size of configuration space read (8, 16, 32 bits)

type C type of value argument

len Length of configuration space read (1, 2, 4 bytes)

Description

Generates rio_mport_read_config_* functions used to access configuration space registers on the local device.

Name

RIO_OP_WRITE — Generate rio_mport_write_config_* functions

Synopsis

```
RIO_OP_WRITE ( size, type, len);
```

Arguments

size Size of configuration space write (8, 16, 32 bits)

type C type of value argument

len Length of configuration space write (1, 2, 4 bytes)

Description

Generates rio_mport_write_config_* functions used to access configuration space registers on the local device.

Device model support

Name

rio_match_device — Tell if a RIO device has a matching RIO device id structure

Synopsis

```
const struct rio_device_id * rio_match_device (const struct
rio_device_id * id, const struct rio_dev * rdev);
```

Arguments

id the RIO device id structure to match against

rdev the RIO device structure to match against

Description

Used from driver probe and bus matching to check whether a RIO device matches a device id structure provided by a RIO driver. Returns the matching struct rio_device_id or `NULL` if there is no match.

Name

rio_device_probe — Tell if a RIO device structure has a matching RIO device id structure

Synopsis

```
int rio_device_probe (struct device * dev);
```

Arguments

dev the RIO device structure to match against

Description

return 0 and set rio_dev->driver when drv claims rio_dev, else error

Name

rio_device_remove — Remove a RIO device from the system

Synopsis

```
int rio_device_remove (struct device * dev);
```

Arguments

dev the RIO device structure to match against

Description

Remove a RIO device from the system. If it has an associated driver, then run the driver `remove` method. Then update the reference count.

Name

rio_match_bus — Tell if a RIO device structure has a matching RIO driver device id structure

Synopsis

```
int rio_match_bus (struct device * dev, struct device_driver * drv);
```

Arguments

dev the standard device structure to match against

drv the standard driver structure containing the ids to match against

Description

Used by a driver to check whether a RIO device present in the system is in its list of supported devices. Returns 1 if there is a matching struct rio_device_id or 0 if there is no match.

Name

rio_bus_init — Register the RapidIO bus with the device model

Synopsis

```
int rio_bus_init ( void);
```

Arguments

void no arguments

Description

Registers the RIO mport device class and RIO bus type with the Linux device model.

Sysfs support

Name

rio_create_sysfs_dev_files — create RIO specific sysfs files

Synopsis

```
int rio_create_sysfs_dev_files (struct rio_dev * rdev);
```

Arguments

rdev device whose entries should be created

Description

Create files when *rdev* is added to sysfs.

Name

rio_remove_sysfs_dev_files — cleanup RIO specific sysfs files

Synopsis

```
void rio_remove_sysfs_dev_files (struct rio_dev * rdev);
```

Arguments

rdev device whose entries we should free

Description

Cleanup when *rdev* is removed from sysfs.

PPC32 support

Name

fsl_local_config_read — Generate a MPC85xx local config space read

Synopsis

```
int fsl_local_config_read (struct rio_mport * mport, int index, u32 offset, int len, u32 * data);
```

Arguments

mport	RapidIO master port info
index	ID of RapdiIO interface
offset	Offset into configuration space
len	Length (in bytes) of the maintenance transaction
data	Value to be read into

Description

Generates a MPC85xx local configuration space read. Returns `0` on success or `-EINVAL` on failure.

Name

fsl_local_config_write — Generate a MPC85xx local config space write

Synopsis

```
int fsl_local_config_write (struct rio_mport * mport, int index, u32
offset, int len, u32 data);
```

Arguments

mport RapidIO master port info

index ID of RapdiIO interface

offset Offset into configuration space

len Length (in bytes) of the maintenance transaction

data Value to be written

Description

Generates a MPC85xx local configuration space write. Returns `0` on success or `-EINVAL` on failure.

Name

fsl_rio_config_read — Generate a MPC85xx read maintenance transaction

Synopsis

```
int fsl_rio_config_read (struct rio_mport * mport, int index, u16 destid,
u8 hopcount, u32 offset, int len, u32 * val);
```

Arguments

mport	RapidIO master port info
index	ID of RapdiIO interface
destid	Destination ID of transaction
hopcount	Number of hops to target device
offset	Offset into configuration space
len	Length (in bytes) of the maintenance transaction
val	Location to be read into

Description

Generates a MPC85xx read maintenance transaction. Returns `0` on success or `-EINVAL` on failure.

Name

fsl_rio_config_write — Generate a MPC85xx write maintenance transaction

Synopsis

```
int fsl_rio_config_write (struct rio_mport * mport, int index, u16 destid, u8 hopcount, u32 offset, int len, u32 val);
```

Arguments

mport	RapidIO master port info
index	ID of RapdiIO interface
destid	Destination ID of transaction
hopcount	Number of hops to target device
offset	Offset into configuration space
len	Length (in bytes) of the maintenance transaction
val	Value to be written

Description

Generates an MPC85xx write maintenance transaction. Returns `0` on success or `-EINVAL` on failure.

Name

fsl_rio_setup — Setup Freescale PowerPC RapidIO interface

Synopsis

```
int fsl_rio_setup (struct platform_device * dev);
```

Arguments

dev platform_device pointer

Description

Initializes MPC85xx RapidIO hardware interface, configures master port with system-specific info, and registers the master port with the RapidIO subsystem.

Chapter 5. Credits

The following people have contributed to the RapidIO subsystem directly or indirectly:

1. Matt Porter<mporter@kernel.crashing.org>
2. Randy Vinson<rvinson@mvista.com>
3. Dan Malek<dan@embeddedalley.com>

The following people have contributed to this document:

1. Matt Porter<mporter@kernel.crashing.org>